

How to Show a Video through the Projector in the Language Media Center

1. Put the videotape in the VCR. Make sure that it is re-wound and cued to the place where you want to start.
2. On the Projector Control box, press the ON button.
3. To make sure that the video input is selected, press the VIDEO 1 button.
4. Start the videotape in the VCR by pushing PLAY.
5. To adjust the speaker volume, use the volume controls on the remote control for the projector. This remote control is gray. Be sure to point the remote control at the front of the projector.

If you want your students to listen through the headsets, follow the instructions for Robotel, but don't click on SEND SCREEN.

To stop the tape and conclude the session:

6. Press STOP on the VCR to stop the videotape.
7. Projector Control, press the OFF button.